




SHELL AND TUBE COOLER ASSEMBLY

10RT


MODEL NUMBER KEY



ORDERING REPLACEMENT PARTS

TO ORDER REPLACEMENT PARTS FOR THE 10RT FROM CARRIER, THE COMPLETE UNIT SERIAL NAMEPLATE DATE (MODEL NUMBER AND SERIAL NUMBER) MUST BE GIVEN ALONG WITH A DESCRIPTION OF THE PARTS NEEDED.

INTERNAL FIN STRAIGHT TUBE DX COOLER (For Refrigerants 12, 22, 500 and 502)



The 10RT shell-and-tube cooler assembly consists of a cooler, complete with refrigerant connections, water connections, thermostats, equalizer connections, and 3/4-in. armaflex insulation. Basic assembly does not include expansion valves, solenoid valves, control thermostats or safety thermostats. Cooler is constructed and tested in accordance with the latest ASME code for unfired pressure vessels.