






* PREFERRED TERMINOLOGY


COMMON TERMINOLOGY FOR CENTRIFUGAL FAN COMPONENTS




ARRANGEMENT 1




ARRANGEMENT 2




ARRANGEMENT 3




VARIABLE VOLUME INLET GUIDE VANE




ARRANGEMENT 4




ARRANGEMENT 8




ARRANGEMENT 9



27DJ



27DK



27DL



CENTRIFUGAL FAN UNITS

27
CD,DJ,DK,DL

Ordering instructions for replacement parts used on 27CD,DJ,DK and DL Centrifugal Fan Units.

1. MOTORS

Repair or replace locally. If a replacement is unavailable locally, order from Carrier (see address below) by giving complete motor nameplate data (frame size, HP, manufacturer, voltage, phase, etc.) and the unit serial nameplate data (unit size, serial number, etc.).

2. BEARINGS

Replace locally. If a replacement is unavailable, order from Carrier (see address below) by giving complete unit serial nameplate data (unit size, serial number, etc.) and the bearing nameplate data, if available (manufacturer, manufacturer's part number, bore size, etc.).

3. DRIVES

Belts and pulleys are to be replaced locally. If two or more belts are used, all belts should be replaced in a matched set.

4. FAN WHEELS, SHAFTS AND ACCESSORIES

Order from Carrier (see address below) by giving complete unit serial nameplate data (unit size, serial number, etc.).